FERNHAVEN – TV AND APPLE REMOTE INSTRUCTIONS

To turn the TV on, check the TV is plugged in and press the Power button on the TV remote.

Push the Source button on the TV remote to select HDMI2. Click the Menu button on the Apple TV remote.

The top third of the Apple TV remote is a touchscreen surface. You can scroll around the Apple TV interface using this trackpad.

When you want to select something press the trackpad.

You can fast forward or rewind a movie or TV show by sliding your finger left or right on the trackpad.

Press the Menu button on the remote to go back a step, press again to go back to the main Apple TV interface.